

OZZ XB1 20"

88202 (black)

Before installation

1. Check the local laws and regulations and the region your vehicle may travel to for LED Light Bar before installation, ensure they are compliance.
2. Read all installation instructions.
3. Make sure the dimension and weight of the lamps and device are matched to your vehicle, see figure 01.
4. Slight moisture inside may exist, it will be removed out from the vent after 2-4 time working.
5. Working Voltage: 10-32V DC.

Mounting

1. Drill 8.5mm holes for screw placement on the surface where you would like to fix the light.
2. Use the bolt to fasten the lamp, add the locking washer and tighten the bolt.
3. Illustration of multi mounting options: side bracket and bottom bracket.

Wiring connections & Functions

1. Wiring connections

Black: Ground,-
Red: Driving light for Off road, boost function,+
Blue: Driving light on road (E-mark),+
White: Reflector Dynamic (white),+

2. Wiring harness, 40A relay, 30A fuse.

Figure 01

