

OZZ WB1 P20" 65

88505 (black)

Before installation

1. Before installation, check local laws and regulations, as well as those of any regions your vehicle may travel to, to ensure the auxiliary lights comply with all requirements.
2. Carefully read all installation instructions prior to beginning.
3. Verify that the dimensions and weight of the lamps and devices are suitable for your vehicle, see figure 01.
4. Unpack the product and check that the lamp housing or lens is not damaged when removing it from the packaging.
5. Ensure the power is turned off during installation.
6. A small amount of internal moisture may occur but will be expelled through the vent after 2-4 operating cycles.
7. Operating Voltage: 10-32V DC.

Mounting

1. Drill 8.5 mm holes on the surface where you intend to install the light for screw placement.
2. Use the bolt to fasten the lamp, add the locking washer, and tighten the bolt securely.
3. Connect black cable to ground (-).
4. Connect red cable to positive (+).
5. To synchronise multiple units (max 10 pcs) connect the white cables together, and keep connected otherwise units will fall out of sync.
6. To switch between day and night mode, apply the white cables to positive (+) for 1 second, and then release.

Figure 01. shows multi mounting options: side bracket and bottom bracket.

Wiring connections & Functions

Black: Ground, -
Red: Flood light, +
Yellow: R65 function by day, +
White: Day/night mode/sync, +
Blue: Red position light on reflector, +

Wiring harness: 40A relay, 30A fuse.

Figure 01

