

OZZ WB1

88504

Before installation

1. Check the local laws and regulations for LED light bars in your area and any regions your vehicle may travel to before installation to ensure compliance.
2. Read all installation instructions thoroughly.
3. Ensure the dimensions and weight of the lamps and devices are suitable for your vehicle; see Figure O1 for reference.
4. Slight moisture inside the light bar may be present initially but will dissipate through the vent after 2-4 uses.
5. Operating Voltage: 10-32V DC.

Mounting

1. Drill 8.5 mm holes on the surface where you intend to install the light for screw placement.
2. Use the bolt to fasten the lamp, add the locking washer, and tighten the bolt securely.
3. Illustration of multiple mounting options: side bracket and bottom bracket.

Wiring connections & Functions

1. Wiring connections
Black: Ground,-
Red: Flood Beam,+
2. Wiring harness, 40A relay, 30A fuse.

Figure O1

